FO	ECH User's Manual	No.	EGP-04-09-001
EG		Enacted Date	2005.01.05
EGCON	DG1	Page	1 / 24

1. WARNING

To prevent personal injury or equipment damage, only qualified technicians/operators should install, operate or service this device.

2. CAUTION

Megger and high potential test equipment should not be used. Incorrect use of such equipment could damage components contained in the unit.

3. APPLICATION

It has been designed to start, stop and protect diesel engine generator automatically or manually.

4. FEATURES

- 4.1. Dry contact as an automatic operation signal is able to be used.
- 4.2. Includes OPG(Oil Press. Gauge), WTG(Water Temp. Gauge), DCV(DC Voltage), engine hour meter.
- 4.3. Engine is stopped by EPB, over speed, low oil pressure, high water temperature and over voltage.
- 4.4. Display by inputting to a relay externally, and engine stop function.
- 4.5. There are OVR, UVR, OCR and a reserved terminal of malfunction input.
- 4.6. Auto-starting can be performed for three times.
- 4.7. Over speed is easily set on the field and PB of over speed test is inside.
- 4.8. Receives voltage of generator or MPU(Magnetic Pickup) signal as an engine run signal.
- 4.9. Protects starter motor by detecting idle speed signal or oil pressure switch.
- 4.10. Operation state is easily recognizable by indicator lamp.
- 4.11. On Auto-start, preheating is able to be performed through the engine preheating plug before starting.
- 4.12. Simplified circuit by using microprocessor.
- 4.13. Surge voltage protecting circuit.
- 4.14. Durable against damp and vibrating environment by silicon molding.
- 4.15. Convenient front mounting.
- 4.16. Selectively use ETR or ETS(modes to stop engine).
- 4.17. Easy engine generator control by including manipulation ability, alarm sound, alarm lamp in ECU.
- 4.18. Dry contacts of engine operation signal and malfunction signal included.

Date

FO	ECII Ilser's Manual	No.	EGP-04-09-001
IĘG		Enacted Date	2005.01.05
EGCON	DG1	Page	2 / 24

4.19. Stop Solenoid circuit included to prevent from being burnt down.

5. BASIC SPECIFICATIONS

- 5.1. Power Input : $12/24Vdc \pm 20\%$
- 5.2. Method of Detecting Generator Voltage(default) \rightarrow 0~75 Hz ,220Vac(7~300 Vac) Method of Detecting MPU(optional) \rightarrow 0~7,000 Hz ,4~30 Vac
- 5.3. Auto-operation signal : dry contact
- 5.4. Spent Time to Start/Stop On Auto-Start(CYCLE CRANKING TIME) : 7 sec.

6. STRUCTURE

- 6.1. Dimension : W220 * H135 * D43 (mm)
- 6.2. Cut-Out : W202*H130
- 6.3. Mounting holes : W212*H60 / 5Φ * 4Holes
- 6.4. Color : dark gray
- 6.5. Weight : about 700g

EGPE-05-01-02(0) A4 (210×297mm EGCON CO., LTD	Modified Date	07,07,31	Modified No.	1
--	------------------	----------	-----------------	---

FO	ECH User's Manual	No.	EGP-04-09-001
IEG		Enacted Date	2005.01.05
EGCON	DG1	Page	3 / 24

7. STRUCTURE

7.1. FRONT VIEW

ENGINE CONTROL UNIT DG1	MODE MOD HORN RESET FAU	E) START T) STOP STOP	
UP NIGHT DOWN W W ULEFT M ULEFT M ULEFT		HH HT	



EGCON CO., LTD	Modified Date	07,07,31	Modified No	1
	Date		I INU.	



7.2. ECU Operation mode and Initializing button



FO	FCII Ilser's Manual	No.	EGP-04-09-001
EG		Enacted Date	2005.01.05
EGCON	DG1	Page	5 / 24



7.3. SET UP KEY



FO	ECI User's Manual	No.	EGP-04-09-001
EG		Enacted Date	2005.01.05
EGCON	egcon DG1		6 / 24

7.4. INDICATOR LAMP



7.4.1. FINE LAMP : turned on when CNT terminal OPENs (GREEN)7.4.2. RUN LAMP : turned on when generator operation signals are input (GREEN)7.4.3. FAULT LAMP : turned on when errors occur during the generator operation (RED)

7.5. Engine error and Protective relay setting matters

	ENGINE	STOP	86X	BUZZER	NOTE
	ENABLE	DISABLE	00/	DOZZEN	
Low oil			\bigcirc	0	
pressure					
High Water	BASE	BASE	\bigcirc	\bigcirc	
temperature	ON	OFF			
Over speed	(Stop)	(Stop selectively)	0	0	
Start failure		selectively)	0	0	
Over voltage			0	0	
Low voltage	OFF (Stop selectively)		0	0	
Over current	OFF (Stop selectively)		0	0	
AFR	OFF (Stop selectively)		0	0	
AFR1	OFF (Stop selectively)		0	0	
AFR2	OFF (Stop selectively)		0	0	
AFR3	OFF (Stop selectively)		0	0	
AFR4	OFF (Stop	selectively)	0	0	

	ECU User's Manual	No.	EGP-04-09-001
E		Enacted Date	2005.01.05
E	DG1	Page	7 / 24
8. k	KINDS OF TIME SETTING		
8.1.	. SDT(Waiting time to start) - 1sec \sim 59sec [Ir	nitial value : 03	Sec]
8.2.	. CDT(Waiting time to stop) - 1sec \sim 59min 59s	sec [Initial valu	ie : 05 Sec]
8.3.	. OFT(Waiting time of detecting oil pressure	error from Idle	Speed signal aft
	starting) - 1sec ~ 59sec [Initial value : 05 Se	ec]	
8.4	. UDT(Waiting time of detecting low voltage from	n Idle Speed s	ignal after starting)
	1sec ~ 59sec [Initial value : 05 Sec]		
8.5.	. OST(Time of blocking start output when oil pro	essure switch is	s on after starting)
0.0	1sec ~ 59sec [Initial value : 05 Sec]		1
8.6.	. STOP(Stop output time at ETS mode) [Initial V	alue : 05 Sec]
	8.6.2. 1 \sim 59sec after all pressure switch CLO	SE	
87	OPE LIVE : Waiting time of detecting LIVE(low	voltage) during	n operation - 1sec
0.7	59sec		
8.8	. OPE. OVR : Waiting time of detecting OVR(ov	er voltage) dur	ing operation - 1s
	~ 59sec	0 , 1	
8.9	. Time setting mode is to press PAGE Key and t	to set at LCD s	creen
. EXT	ERNAL INPUT/OUTPUT TERMINALS AND CONNECTOR	RS	
9.1.	. TERMINALS		
	9.1.1. STT : Start output		
	9.1.2. STP : Stop output		
0.0	9.1.3. DC+ : "+" input of power input		
9.2.	0.2.1 RR+ RR- : Rower input		
	9.2.1. BFT, BFT · Fowel input)/60Hz input	
	9.2.3 MP1 MP2 : Magnetic pickup(MPII) input		
	9.2.4. CNT : Automatic operation contact(AUTC) Mode BP - o	perate when input)
	9.2.5. PH+ : Preheat output(BP+output)		
	9.2.6. G+ : Output when generator and engine	operate(BP+ou	tput)
	9.2.7. 86X-c, 86X-a : Malfunction signal conta	ct(NORMAL OPI	EN)
	9.2.8. 86X-c, 86X-b : Malfunction signal conta	.ct(NORMAL CLO	DSE)
	9.2.9. 6X-c, 6X-a : Operation signal contact(N	ORMAL OPEN)	
	9.2.10. WTS : High water temperature switch in	put(NORMAL O	PEN)
	9.2.11. OPS : Oil pressure switch input(NORMA	L CLOSE)	

9.2.12. EPB : Emergency stop switch input(NORMAL OPEN)

9.2.13. AFR : Reserve error input(NORMAL OPEN)

FO	FCU	llser's	Manual	No.	EGP-04-09-001
EG				Enacted Date	2005.01.05
EGCON	DG1		Page	8 / 24	
0.0.1.1					

9.2.14. OCR : Over current relay input(NORMAL OPEN)

9.2.15. UVR : Under voltage relay input(NORMAL CLOSE)

9.2.16. AFR1~4 : Reserved error input(NORMAL OPEN)

9.2.17. OPU : Oil pressure sensor input

9.2.18. WTU : Coolant temperature sensor input

9.2.19. NC : NO CONNECTION (Terminal not to use)

10. LCD SCREEN DISPLAY

10.1. Battery power is supplied - Buzzer sounds for 2sec

	10.2.	Below	start-up	screen	is	displayed	for	2sec
--	-------	-------	----------	--------	----	-----------	-----	------

					Ε	С	U		D	G	1						
	Е	Ν	G	l	Ν	Ε		С	0	Ν	Т	R	0	L			
					V	Ε	R		0	•	1	Α					
		Ε	G	С	0	Ν		С	0	•	,		L	Т	D	•	

10.3. Initial state - Commercial power is normal and MPU mode is selected.(When oil pressure switch and high water temperature switch are seleted to use)

Μ	0	D	Ε	•	0	F	F		D	С	•	2	6	•	0	V	
С	0	М	•	0	Ν				0	0	0	0	0	R	Ρ	М	
G	Ε	Ν	•	S	Т	0	Ρ		0	Ρ	•	0	Ν				
E	Т	М	•	0	0	0	Н	0	W	Т	•	0	F	F			

10.4. At the start-up screen - If Page Key is pressed,

Page Key operates only in OFF mode

				S	Ε	Т	Т	I	Ν	G	S							
1	•	Т	I	М	Ε		S	Ε	Т	Т	l	Ν	G					
2	٠	Е	Ν	G	l	Ν	Е		S	Е	Т	Т	I	Ν	G			
3	•	Ρ	Α	S	S	W	0	R	D		S	Е	Т	Т	I	Ν	G	

EGCON CO LTD	Modified	07 07 31	Modified	1
EGGON CO., ETD	Date	07,07,51	No.	

FO	ECH User's Manual	No.	EGP-04-09-001
EG		Enacted Date	2005.01.05
EGCON	DG1	Page	9 / 24

10.5. SETTING MODE state - if DOWN KEY is pressed

4	٠	Н	z	&	F	R	E	Q		S	Ε	Т	Т	I	Ν	G		
5	•	Ρ	l	С	К	_	U	Ρ		S	Е	Т	Т	I	Ν	G		
6	•	V	0	L	Т	Α	G	Е		S	Ε	Т	Т	I	Ν	G		
7	•	Е	R	R	0	R		I	Ν	Ρ	U	Т		Т	Y	Ρ	Е	

10.6. SETTING MODE state - if DOWN KEY is pressed.

8	•	S	Ε	Ν	S	0	R		S	Ε	L	Ε	С	Т				
9	•	Ρ	R	0	Т	E	С	Т		S	Е	Т	Т	I	Ν	G		

EGPF-05-01-02(0) A4 (210×297mm EGCON CO., LTD	Modified Date	07,07,31	Modified No.	1
--	------------------	----------	-----------------	---

FO	ECH User's Manual	No.	EGP-04-09-001
EG		Enacted Date	2005.01.05
EGCON	DG1	Page	10 / 24

11. SETTING modification

11.1. SETTING MODE STATE- At No.1 (TIME SETTING) menu, if "RIGHT ▶" pressed

	1	•	Т	I	М	E		S	Ε	Т	Т	I	Ν	G				
>	٠	S	D	Т									0	3	S	Е	С	
2	٠	С	D	Т			0	0	М	I	Ν		0	5	S	Е	С	
3	•	0	S	Т									0	5	S	Ε	С	

11.2. SETTING MODE STATE - At No.1 menu, if "DOWN ▼" is pressed

4	•	0	F	Т					0	5	S	Ε	С	
5	•	U	D	Т					0	5	S	Е	С	
6	•	S	Т	0	Ρ				0	7	S	Е	С	

11.3. Changing S.D.T (Start waiting time)

11.3.1. Using UP/DOWN key, choose S.D.T and press ENTER Key.

11.3.2. Cursor is positioned at 0.

11.3.3. Using UP/DOWN key, change number.

11.3.4. To change next number, press **RIGHT** key.

11.3.5. Cursor is positioned at No.3.

11.3.6. Using UP/DOWN key, Change number.

11.3.7. When completing to change, press $\ensuremath{\mathsf{ENTER}}$ key.

11.3.8. Change other times in the same way.

	1	•	Т	I	М	Ε		S	Ε	Т	Т	I	Ν	G				
>	•	S	D	Т									0	3	S	Е	С	
2	•	С	D	Т			0	0	М	I	Ν		0	5	S	Е	С	
3	•	0	S	Т									0	5	S	Е	С	

11.3.9. After setting, press LEFT key to move to the above setting screen.

				S	Ε	Т	Т	I	Ν	G	S							
1	•	Т	l	М	Е		S	Е	Т	Т	l	Ν	G					
2	•	Е	Ν	G	l	Ν	Ε		S	Е	Т	Т	l	Ν	G			
3	٠	Ρ	Α	S	S	W	0	R	D		S	Ε	Т	T	I	Ν	G	

FA	F	C	U	IJ	se	r':	S	Ma	an	<u></u>	I		No).		EGF	P-04	1-09	9-00	1
EG	-		<u> </u>	<u> </u>							-	Ena	cted	Da	ıte	20)05.	01	. 05	
EGCON	1					DG	1						Pag	ge			11	/ 2	4	
11.4. C	han	geat	ole I	tem	s in	SET	ΓΤΙΝ	GΜ	enu											
1	1.4.	1. 1.	. TIN	NE S	SETT	ING					-					-				
		1	•	Т	1	Μ	Ε		S	E	Т	Т	l	Ν	G					
	>	•	S	D	Т									0	3	S	E	С		
	2	•	С	D	Т			0	0	Μ	l	N		0	5	S	E	С		
	3	•	0	S	Т									0	5	S	E	С		
	4	•	0	F	Т									0	5	S	Е	С		
	5	•	U	D	Т	÷					0			0	5	S	Е	С		
	6	•	S	Т	0	Ρ								0	7	S	Е	С		
	1	1.4 1.4 1.4 1.4	.1.1 .1.2 .1.3	. SL . C(. O(sig . U(sig	DT(S DT(S FT(V gnal DT(V gnal	Stop Vaitin afte Vaitin afte	wai wai ng t er st ng er st	ting ting ime artir time artir	time of o ng) - of of	e) – e) – dete dete c e de – [ting cting Init	nitia pitia g oil ial v ting	i va il va pre alue low	ilue Ilue Issur Ssur Ssur Ssur Ssur Ssur Ssur Ssur	: 0 : 0 : 0 : 0 : 0 : 0 : 0 : 0 : 0 : 0	is Se irror Sec ie fr	ec interpretended int	n Idl Idle	e Spe	eec
	1	1.4 pres 1.4.	.1.5 ssur 1.6.	6. OS e sv STO M 1	ST(F vitch OP(E axim ~ 5	Rang i is ETS num 59se	e of on a moc 20s c af	f sta after de s ec a ter c	top at no pil p	utpu rting outp outp o inp oress	it bl) – out out	ockii [li time] of o swit	ng t nitia) - il pr	ime I va [In essu s O	whe Iue Iitia Ire FF	en o : 0! I val swite	il 5 Se ue	ec] : 05	Sec	:]
1	1 1 1.4.2	1.4 pres 1.4. 2. 2.	.1.5 ssur 1.6.	e sv STO M 1 IGIN	ST(F vitch OP(f axim ~ 5 E Sf	lang TS TS um 9se TTI	e of on a moc 20s c af NG	f sta after de s ec a ter d	top at no pil p	utpu rting outp outp outp ress	it bl) – out out sure	ockii [Ir time] of o swit	ng t nitia) - il pr ch i	ime I va [In essu s O	whe lue iitia ure FF	en o : 0! I val swite	il 5 Se ue	ec] : 05	Sec	:]
1	1 1 1.4.2	1.4 pres 1.4. 2. 2. 2	.1.5 ssur 1.6. EN	e sv ST M 1 IGIN	ST(F vitch OP(f axim ~ 5 E Sf N	Rang TS TS Tum 9se TTI	e of on a mod 20s c af NG	f sta after de s ec a ter o N	top at no pil p	utpu rting outp outp ress	it bl out out sure	ockii [II time) of o swit	ng t nitia) - il pr ch i	ime I va [In essu s O T	whe lue litia lite FF	en o : 0! I val switc	il 5 Se ue ch	ec] : 05	Sec	:]
1	1 1.4.2	1.4 pres 1.4. 2. 2. 2	.1.5 ssur 1.6. EN	e sv ST(M 1 IGIN E Y	ST(F vitch OP(E axim ~ 5 E SE N P	Rang I is ETS Num 59se ETTI G E	e of on a mod 20s c af NG I :	f sta after de s ec a ter o	top at no pil p E E	utpu rting outp outp ress	it bl) – but but sure S R	ockii [li time] of o swit	ng t nitia) – il pr ch i T	ime I va [In essu s O T	who itia itia FF	en o : 0! I val swite	il 5 Se ue ch	€] 205	Sec	:]

11.4.2.1. TYPE : ETR, ETS [Initial value - ETS] 11.4.2.2. OPS MODE : CONT, VAL, NONUSE [Initial value - CONT] 11.4.2.3. WTS MODE : CONT, VAL, NONUSE [Initial value - CONT]

11.4.3. 3. PASSWODRD SETTING



Ν

Ο

3 Ρ d : 1 1 1 1 а S S W 0 r . 11.4.3.1. Setting_PW : NONUSED, USE - [Initial value : NONUSED] - When "USE" is set, if "PAGE" is pressed in OFF mode,

Ρ

W

:

N O

N U

S

Е

password is identified.

Ρ

•

0

W

е

r

2

11.4.3.2. PowerON_PW : NONUSED, USE - [Initial value : NONUSED]
- When "USE" is set and initial power is input, Password is identified.

11.4.3.3. PASSWORD - 1111

11.4.3.4. PASSWORD screen and how to input

			-	-	Ρ	Α	S	S	W	0	R	D	-	_				
							_	_	_	_								
Е	n	t	е	r		k	е	у		Ρ	r	е	S	S	•	•	•	

11.4.3.4.1. When using PASSWORD is set, above screen is displayed. 11.4.3.4.2. Press ENTER KEY.

11.4.3.4.3. Using UP/DOWN KEY, change number.

			-	-	Ρ	Α	S	S	W	0	R	D	-	_				
							1	_	_	_								
R	I	G	Н	Т		k	е	у	•	Ρ	r	е	S	S	•	•	•	

11.4.3.4.4. If the first number is changed, change the remaining numbers by using "RIGHT" KEY.

			-	-	Ρ	Α	S	S	W	0	R	D	-	—				
							1	1	1	1								
Е	n	t	е	r		k	е	у		Ρ	r	е	S	S	•	•	•	

11.4.3.4.5. After choosing numbers to the 4th by using UP/DOWN key,

FO	ECI User's Manual	No.	EGP-04-09-001
EG		Enacted Date	2005.01.05
EGCON	DG1	Page	13 / 24

press ENTER KEY to confirm PASSWORD.

11.4.3.4.6. This screen is printed when a wrong PASSWORD is input.

			-	-	Ρ	Α	S	S	W	0	R	D	-	_				
							1	1	1	4								
F	Α	I	L		Ρ	r	е	S	S		Е	Ν	Т	Е	R	•	•	
С	а	n	с	е	I		Ρ	r	е	S	S		Ρ	Α	G	Е	•	

- 11.4.3.4.7. If ENTER key is pressed, screen is changed to PASSWORD setting, and if PAGE key is pressed, screen displays MAIN PAGE.
- 11.4.3.4.8. When power is supplied, if you don't know PASSWORD at the password setting, impossible to go to MAIN PAGE.
- 11.4.4. 4. Hz&Freq SETTING

	4	•	Н	z	&	F	r	е	q	S	E	Т	Т	I	Ν	G	
2	•	6	0	Н	Ζ												

11.4.4.1. 1, 50Hz

11.4.4.2. 2. 60Hz

11.4.4.3. 3. PICK UP [Initial value]

11.4.5. 5. PICK-UP SETTING

	5	•	Ρ	I	С	Κ	_	U	Ρ		S	Е	Т	Т	I	Ν	G		
>	•	G	Е	Α	R		Ν	U	М	В	Е	R	:	1	2	1	Е	Α	

11.4.5.1. Input the number of engine ring gear - [Initial value : 121 EA]

EGCON CO., LTD	Modified Date	07,07,31	Modified No.	1
----------------	------------------	----------	-----------------	---

FO	ECH User's Manual	No.	EGP-04-09-001
EG		Enacted Date	2005.01.05
EGCON	DG1	Page	14 / 24

6. VOLTAGE SETTING (* NOT USED AT THE PRESENT VERSION*)

	6	•	۷	0	L	Т	Α	G	Ε	S	Ε	Т	Т	I	Ν	G		
1	•	G	Ε	Ν		U	۷	R	•		1	8	0	•	0	۷		
2	•	0	Ρ	Е	•	U	۷	R	•						5	S	Е	С
3	•	G	Ε	Ν		0	۷	R	•		2	3	5	•	0	۷		

	6	•	۷	0	L	Т	Α	G	Ε		S	Ε	Т	Т	I	Ν	G		
4	•	0	Ρ	Е		0	۷	R	•							5	S	Е	С
5	•	0	۷	Е	R		S	Ρ	Ε	Е	D	•	2	1	5	0	R	Ρ	М

11.4.5.1. 1. GEN UVR : 000.0 ~ 299.9Vac (Initial value : 180.0Vac)

11.4.5.2. 2. OPE. UVR : 0 \sim 9sec (Initial value : 5sec)

11.4.5.3. 3. GEN OVR : 000.0 \sim 299.9Vac (Initial value : 235.0Vac)

11.4.5.4. 4. OPE. OVR : 0 \sim 9sec (Initial value : 5sec)

11.4.5.5. 5. OVER SPEED : 0000 ~ 2999 rpm (Initial value : 2150 rpm) 11.4.6. 7 ERROR INPUT

	7	•	Е	R	R	0	R		l	Ν	Ρ	U	Т		Т	Y	Ρ	Ε	
1	•	Т	Y	Ρ	Ε	:	Е	Х	Т	•		С	0	Ν					

TYPE : INT. VAL - Use OVR, UVR relays as an internal measured value. TYPE : EXT. CON - Use external relays of OVR, UVR. (* Initial value *)

11.4.7. 8. SENSOR SELECT

FA	F	-C	U	[]	se	r':	S	Ma	an	แล	Ι		No).		EGP	2 -04	1-0	9-0	01
I-G	<u> </u>		<u> </u>	<u> </u>						uu	-	Ena	ctec	l Da	ıte	20	005.	01	. 05	5
EGCON	1				[DG	1						Pag	ge			15	/ 2	24	
		8	•	S	E	Ν	S	0	R		S	E	L	E	С	Т				
	1	٠	0	Ρ		Μ	0	D	Ε	L	•		۷	D	0					

MODEL:

D O N G N A M

11.4.7.1. OP MODEL : VDO, DONGNAM (Choosing oil pressure sensor, initial value - VDO) - Make sure to use VDO

- 11.4.7.2. WT MODEL : VDO, DONGNAM, EG CON (Choosing coolant temperature sensor, initial value DONGNAM)
- 11.4.8. 9. PROTECT SETTING

2 . W T

	9	٠	Ρ	R	0	Т	E	С	Т		S	Ε	Т	Т	I	Ν	G	
1	•	В	Α	S	Е	•		0	Ν									
2	•	U	V	R	:			0	F	F								
3	•	0	С	R	:			0	F	F								

	9	•	Ρ	R	0	Т	Ε	С	Т		S	Е	Т	Т	I	Ν	G	
4	•	Α	F	R	•			0	F	F								
5	•	Α	F	R	1	•		0	F	F								
6	•	Α	F	R	2	•		0	F	F								

	9	٠	Ρ	R	0	Т	Е	С	Т		S	E	Т	Т	I	Ν	G	
7	•	Α	F	R	3	•		0	F	F								
8	•	Α	F	R	4	•		0	F	F								

11.4.8.1. BASE : ON, OFF [Initial value : ON]
11.4.8.2. UVR : ON, OFF [Initial value : OFF]
11.4.8.3. OCR : ON, OFF [Initial value : OFF]
11.4.8.4. AFR : ON, OFF [Initial value : OFF]
11.4.8.5. AFR1 : ON, OFF [Initial value : OFF]
11.4.8.6. AFR2 : ON, OFF [Initial value : OFF]
11.4.8.7. AFR3 : ON, OFF [Initial value : OFF]
11.4.8.8. AFR4 : ON, OFF [Initial value : OFF]

FO	ECH User's Manual	No.	EGP-04-09-001
EG		Enacted Date	2005.01.05
EGCON	DG1	Page	16 / 24

12. LCD start-up screen according to setting

	Sensing speed of	Voltage
	generator	Voltage
		CONT(Choosing switch of oil
		pressure)
101	Coolont tomporatura	CONT(Choosing switch of
12.1.		coolant temperature)

Μ	0	D	Ε	:	Μ	Α	Ν	U	D	С	•	2	6	•	0	V	
С	0	М	•	0	Ν							0	0		Н	z	
G	Е	Ν	:	S	Т	0	Ρ		0	Ρ	•	0	Ν				
Ε	Т	М	:	0	0	0	Н	0	W	Т	•	0	F	F			

	Sensing speed of	MPLI(Magnetic nickup)
	generator	
		CONT(Choosing switch of oil
		pressure)
100	Coolont tomporatura	CONT(Choosing switch of
12.2.		coolant temperature)

Μ	0	D	E	:	Μ	Α	Ν	U	D	С	•	2	6	•	0	۷	
С	0	М	•	0	Ν				0	0	0	0	0	R	Ρ	М	
G	Е	Ν	:	S	Т	0	Ρ		0	Ρ	:	0	Ν				
E	Т	М	•	0	0	0	Н	0	W	Т	•	0	F	F			

	Sensing speed of	Voltago
	generator	voltage
	Oil pressure	VAL (Oil pressure sensor)
10.0	Coolant tomporaturo	VAL (Coolant temperature
12.3.		sensor)

М	0	D	Е	•	М	А	Ν	U	D	С	•	2	6	•	0	۷		
С	0	М	•	0	Ν							0	0		Н	z		
G	Ε	Ν	•	S	Т	0	Ρ		0	Ρ	•	0	0	•	0	0	κ	G
Е	Т	М	•	0	0	0	Н	0	W	Т	•				0	0	0	С

F	F	CI		9	er	's	٨	۸a	nı	ıal			No.		E	GP-	-04-	-09-001
EG						0		''a		a	—E	nac	ted	Date	е	200)5.	01.05
EGCON	n				D	G1						F	Page	;		1	7 /	′24
	Sen	sing ger	, sp nera	eed tor	of			MP	U(M	agn	etic	; pic	kup)				
	C	Dil p	ores	sure			V	AL	(Oil	pre	ssu	ire s	ens	or)				
12.4.	Coola	ant	tem	pera	ature	•	١	/AL	(Cc	olar sen	nt t sor	emp)	erat	ure				
MC	D	Е	:	Μ	A	Ν	U		D	С	:	2	6	•	0	۷		
СС) M	•	0	Ν					0	0	0	0	0	R	Ρ	Μ		
GE	E N	•	S	Т	0	Ρ			0	Ρ	:	0	0	•	0	0	К	G
E 1	ГМ	•	0	0	0	Н	0		W	Т	•				0	0	0	С

	Sensing speed of	Voltago
	generator	Voltage
	Oil pressure	NONUSE
12.5.	Coolant temperature	NONUSE

М	0	D	Ε	:	М	А	Ν	U	D	С	•	2	6	•	0	V		
С	0	М	•	0	Ν							0	0		Н	z		
G	Е	Ν	•	S	Т	0	Ρ		0	Ρ	•	Ν	0	Ν	U	S	Е	
E	Т	М	•	0	0	0	Н	0	W	Т	•	Ν	0	Ν	U	S	E	

	Sensing speed of generator	MPU(Magnetic pickup)
	Oil pressure	NONUSE
12.6.	Coolant temperature	NONUSE

М	0	D	Ε	•	М	Α	Ν	U	D	С	•	2	6	•	0	۷		
С	0	М	•	0	Ν				0	0	0	0	0	R	Ρ	М		
G	Е	Ν	•	S	Т	0	Ρ		0	Ρ	•	Ν	0	Ν	U	S	Е	
Ε	Т	Μ	•	0	0	0	Н	0	W	Т	•	Ν	0	Ν	U	S	Е	

No.

FCU	llser's	Manual	No.	EGP-04-09-001
	0301 3	Manual	Enacted Date	2005.01.05
EGCON	DG1		Page	18 / 24

13. PREPARATIONS BEFORE USE

- 13.1. Connect the circuit to in/output terminals of ECU-DG1 like below [Drawing1].
- 13.2. Set up the basic settings of ECU-DG1 in accordance with engine.
 - ▶ Engine stop mode ETS/ETR
 - ▶ When engine speed sensing is set as voltage or MPU type, set it in accordance with the number of engine ring gear.
- 13.3. Supply power.
- 13.4. If ECU in/output terminals' connections are different from Drawing1, the alarm sounds and the different connections from Drawing1 are displayed on LCD as faults.



14. MANUAL START TEST

[DRAWING 1]

- 14.1. Set ECU-DG1 as MANU by using the mode setting button.
- 14.2. Displayed items from below LCD screen : MANU mode, sensing generator speed by MPU, Commercial power is normal, and oil pressure switch, and high water temperature switch contact is selected.

EGCON CO., LTD	Modified Date	07,07,31	Modified No.	1	
----------------	------------------	----------	-----------------	---	--

		2		=C		U	se	r's	5	Ma	an	Па			No).		EG	P-0	4-09	-001
	-	G	<u> </u>		<u> </u>	U			<u> </u>				••	Ena	cted	d Da	ate	2	005	. 01.	05
e	GC		1				I	DG	1						Pa	ge			19	/ 24	Ļ
	-	_	_								-			-					-	7	
Μ	0	D	E	•	Μ	Α	Ν	U		D	С	•	2	6	•	0	V				
С	0	М	:	0	Ν					0	0	0	0	0	R	Ρ	М				
G	Е	Ν	•	S	Т	0	Ρ			0	Ρ	•	0	Ν							
F	Т	М	÷	0	0	0	н	0		W	Т	•	0	F	F						

14.3. Press START button and engine starts.

- If only starter motor operates and engine does not start, check engine stop mode.

- When engine starts normally without error, the present RPM is indicated, and after OFT, OST times, When oil pressure switch operates normally and when the state is GEN : RUN, LCD screen is changed to OP : OFF.

- When engine speed is different from indicated RPM value, after engine stops, reset after confirming engine gear number of PICK-UP SETTING of SETTING mode No.5.

- If normally operating time of engine is more than 6min, ETM will increase.

Μ	0	D	Е	•	М	Α	Ν	U	D	С	•	2	6	•	0	۷	
С	0	М	:	0	Ν				0	1	7	9	7	R	Ρ	М	
G	Е	Ν	:	R	U	Ν			0	Ρ	•	0	F	F			
Е	Т	М	:	0	0	0	Н	0	W	Т	•	0	F	F			

* ETM : 000H1 - Operating time is 6min. or more.

* ETM : 001H3 - Operating time is an hour and 18min. or more.

▶ When engine operation signal is more than 30% of rated rotating speed, the power of starter motor is cut off.

▶ If oil pressure switch operates owing to detecting oil pressure switch even without engine operating input when engine starts, the power of starter motor is cut off after OST time.

► If operating signal of more than 30% of rated speed is input to GP1/GP2 terminal or MP1/MP2 terminal with normal operation of engine, RUN lamp is indicated.

▶ If oil pressure switch does not operate for more than OFT time at more than 30%(IDLE SPEED) of rated speed, faults detecting engine of low oil pressure stops.

▶ If no engine operating signal and no oil pressure switch signal, starting output is maintained for 7sec, and then cut off.

▶ If engine operating signal has no input(less than 30% of rated speed) and oil pressure switch operates, output of starter motor is cut off and engine

FO	ECH User's Manual	No.	EGP-04-09-001
EG		Enacted Date	2005.01.05
EGCON	DG1	Page	20 / 24

operates normally.

▶ If RUN lamp is turned on, battery "+" is output from G+ terminal, and operating power of gauge is supplied, and 6X operates, and so operating signal is sent remotely.

- 14.4. ENGINE STOP
 - ▶ Press STOP button or press MODE button to be off, and the engine stops.

ETR : If electricity is supplied to fuel solenoid, engine operates. If electricity is cut off to fuel solenoid, engine stops.

ETS : Engine stops when electricity is supplied to Fuel solenoid.

If oil pressure switch is OFF, the power output is cut off after STOP time. If oil pressure switch is not off, the power outputs only for about 20sec. and cut off.

- 14.5. When engine operates normally, if EPB is pressed, and if engine protection circuit(over speed, high water temperature, low oil pressure) or generator protection circuit(OVR) runs, engine stops.
- 14.6. Displayed items : MANU mode, sensing generator speed by MPU, commercial power is normal, setting as using sensor after oil pressure and high water temperature sensors are connected.

Μ	0	D	Е	•	М	Α	Ν	U	D	С	•	2	6	•	0	۷		
С	0	Μ	:	0	Ν				0	0	0	0	0	R	Ρ	М		
G	Е	Ν	:	S	Т	0	Ρ		0	Ρ	•	0	0	•	0	0	Κ	G
E	Т	М	:	0	0	0	Н	0	W	Т	•				0	0	٥	С

14.7. Press START button, and engine starts.

- If only starting motor run and engine does not start, engine stop mode needs to be confirmed.

- When engine starts normally without error, the present RPM is indicated, and after OFT, OST times, if oil pressure sensor operates normally and screen displays GEN : RUN, screen is changed to OP : XX.XX KG.

- When engine speed is different from indicated RPM figure, after engine stops, reset after confirming engine gear number of PICK-UP SETTING of SETTING mode No.5.

- If normally operating time of engine is more than 6min., ETM will increase.

EGCON CO., LTD	Modified Date	07,07,31	Modified No	1
	Dail		1 10.	

-	2	E	C	U	U	se	r':	s I	Ma	inu	al		No).		EGP	P-04	1-09	9-0()1
	9	_										Ena	cteo	l Da	ıte	20)05.	01	. 05)
EGC	.00					Ľ)G	1					Pa	ge			21	/ 2	24	
		•	<u> </u>			•	•	N 1			<u> </u>		•	•		•	<u>\</u>			
	M	Ο	ט	E	•	M	Α	N	U	U	C		2	6	•	0	V			
	С	0	М	:	0	Ν				0	1	7	9	7	R	Ρ	М			
	G	Е	Ν	•	R	U	Ν			С	Ρ	:		5	•	4	4	Κ	G	
	F	Т	М	:	0	0	0	н	0	W	' T	:				0	0	0	С	

▶ When engine operation signal is more than 30% of rated speed, the power of starter motor is cut off.

▶ When engine starts, if oil pressure is over 3 Bar(3kg/cm²) detected from oil pressure sensor, the power of starting motor is cut off after OST time even without engine operation input.

► If operating signal of more than 30% of rated speed is input to GP1/GP2 terminal or MP1/MP2 terminal resulting from normal operation of engine, RUN lamp is indicated.

▶ When oil pressure sensor does not operate for more than OFT time at more than 30%(IDLE SPEED) of rated speed, if the figure is below 1Bar(1Kg/ord), fault detecting engine of low oil pressure stops.

▶ In case of no engine operating signal and no oil pressure sensor signal, start output is maintained just for 7sec and then cut off.

▶ If engine operating signal has no input(less than 30% of rated speed) and oil pressure sensor is detected, output of starting motor is cut off and engine operates normally.

▶ If RUN lamp is turned on, battery "+" is output from G+ terminal, and operating power of gauge is supplied, and 6X operates, and so, operating signal is sent remotely.

14.8. ENGINE STOP

▶ Press STOP button or press MODE button to be off, and the engine stops.

ETR : If electricity is supplied to fuel solenoid, engine operates. If electricity is cut off to fuel solenoid, engine stops.

ETS : Engine stops when electricity is supplied to Fuel solenoid.

If oil pressure sensing value is below 1Bar(1Kg/orf), the power input is cut off after STOP time. If oil pressure sensing value is not

	ECH User's Manual	No.	EGP-04-09-001		
		Enacted Date	2005.01.05		
	DG1	Page	22 / 24		

1Bar(1Kg/cm²), the power input is output only for about 20sec. and cut off.

14.9. When engine operates normally, if EPB is pressed, if engine protection circuit(over speed, over temperature, low oil pressure) or generator protection circuit(OVR) runs, engine stops.

15. Automatic operation test

- 15.1. Select AUTO MODE.
- 15.2. If CNT terminal is "OPEN", engine does not start.
- 15.3. If CNT terminal is "CLOSE", after S.D.T(start waiting time/1sec \sim 59sec) time, engine starts.
- 15.4. If CNT terminal is "CLOSE" and if CNT terminal is "OPEN" before S.D.T time, engine doesn't start and S.D.T time is initialized.
- 15.5. If CNT terminal is "CLOSE", battery "+" is output from PH+(engine preheating output) and Engine ouput is cut off at more than 30% of engine operating speed.
- 15.6. If more than 30% of engine operating speed is not input after start output is put out, GCU repeats to put out and to pause start output for 7sec. respectively for three times overall. If more than 30% of engine operating speed is eventually not input for the three times, engine is stopped, being recognized to fault.
- 15.7. If start output is put out and oil pressure switch is ON, start output is cut off after OST time.
- 15.8. When engine operates normally, RUN LAMP is indicated.
- 15.9. If commercial power returns(CNT terminal OPEN) during engine normal operation, engine stops after preparing for re-off for C.D.T TIME(engine cooling time/1sec ~ 59min 59sec) and after cooling engine.

	Auto-operation input signal	Engine state	Nata
NO	CNT	Engine state	Note
1	OPEN	Stop	
2	CLOSE	Run	

F	FCII Ilser's Manual	No.	EGP-04-09-001		
EG		Enacted Date	2005.01.05		
EGCON	DG1	Page	23 / 24		

- 16. Operating test of the engine and generator protecting devices (same at manual or automatic)
 - ► After protecting device operates, RESET can be RESET after Buzzer stop.
 - 16.1. EPB (EMERGENCY PUSH BUTTON)
 - 16.1.1. Start engine.
 - 16.1.2. Confirm whether RUN lamp of ECU is turned on or RPM METER indicates normal RPM.
 - 16.1.3. Press EPB.
 - 16.1.4. EPB lamp is turned on, buzzer sounds, and engine stops.
 - 16.1.5. Press Buzzer Stop, Release EPB, and press RESET.

*	*	*	Е	R	R	0	R	_	_	М	Е	S	S	Α	G	Е	*	*	*
					Е	Ρ	В		Е	R	R	0	R						
	Н	0	Ε	Ν			R	S	Е	S	Т		Ρ	R	Ε	S	S		

- Screen when EPB(EMERGENCY PUSH BUTTON) is input

*	*	*	Ε	R	R	0	R	_	_	Μ	Е	S	S	Α	G	Ε	*	*	*
					Е	Ρ	В		Е	R	R	0	R						
	F	Α	U	L	Т		R	S	E	S	Т		Ρ	R	Ε	S	S		

- Screen after HORN RESET P/B is input

Μ	0	D	Е	•	0	F	F		D	С	•	2	6	•	0	۷	
С	0	Μ	÷	0	Ν				0	0	0	0	0	R	Ρ	Μ	
G	Ε	Ν	:	S	Т	0	Ρ		0	Ρ	•	0	Ν				
E	Т	Μ	•	0	0	0	Н	0	W	Т	•	0	F	F			

- Screen after inputting FAULT RESET P/B
- MODE OFF is initialized.
- 16.2. OVER SPEED TEST
 - Over speed test can be performed at any state.
 - ► OVER SPEED SETTING value is changed.
 - SETTING MANU
 - 6. VOLTAGE SETTING
 - 6.5 : Changing value to the value to be wanted at OVER SPEED
 - Initial value : 2150RPM
 - 16.2.1. Start Engine.

Modified

No.

	ECII Ilser's Manual	No.	EGP-04-09-001
		Enacted Date	2005.01.05
	DG1	Page	24 / 24

16.2.2. Confirm RUN lamp indication and RPM of ECU.

16.2.3. Press OST (OVER SPEED TEST) PB.

16.2.4. OSL lamp is indicated, Buzzer sounds, Engine stops.

16.2.5. LCD screen displays OVER SPEED ERROR_MESSAGE.

16.2.6. Press Buzzer Stop, and RESET.

16.3. OPL(LOW OIL PRESSURE)

▶ Oil pressure switch is related to Stop Output of starter motor and ETS TYPE.

► After Engine starts, if Oil Pressure Switch operates, Output of the Starter motor is cut off. When Engine stops, if Oil Pressure Switch is "OFF", stop output is cut off in case of ETS TYPE.

16.3.1. When setting for Oil Pressure Switch

16.3.1.1. Start Engine.

- 16.3.1.2. Confirm RUN lamp indication RPM of ECU.
- 16.3.1.3. Earth OPS terminal.
- 16.3.1.4. Buzzer sounds, Engine stops.
- 16.3.1.5. LCD screen displays OPS ERROR_MESSAGE.
- 16.3.1.6. Press Buzzer stop, and RESET.
- 16.3.2. When setting for Oil Pressure Sensor
 - 16.3.2.1. Start Engine.
 - 16.3.2.2. Confirm RUN lamp indication and RPM of ECU.
 - 16.3.2.3. Faults are detected when OPU connecting terminal OPENs or when Engine oil sensing value in operation is below 1Bar(1Kg/ cm²).
 - 16.3.2.4. Buzzer sounds, and Engine stops.
 - 16.3.2.5. LCD screen displays OPS ERROR_MESSAGE.
 - 16.3.2.6. Press Buzzer Stop, and RESET.
- 16.4. WTL (Over temperature HIGH WATER TEMPERATURE)

16.4.1. When setting for Over temperature Switch

- 16.4.1.1. Start Engine.
- 16.4.1.2. Confirm RUN lamp indication and RPM of ECU.
- 16.4.1.3. Earth WTS terminal.
- 16.4.1.4. Buzzer sounds, and Engine stops.
- 16.4.1.5. LCD screen displays WTS ERROR_MESSAGE.
- 16.4.1.6. Press Buzzer stop, and RESET.
- 16.4.2. When setting for temperature sensor
 - 16.4.2.1. Start Engine.
 - 16.4.2.2. Confirm RUN lamp indication and RPM of ECU.

EG	ECH User's Manual	No.	EGP-04-09-001		
		Enacted Date	2005.01.05		
EGCON	DG1	Page	25 / 24		

- 16.4.2.3. Faults are detected when WTU connecting terminal OPENs or when temperature sensing value is more than 105°C.
- 16.4.2.4. Buzzer sounds, and engine stops.
- 16.4.2.5. LCD screen displays WTS ERROR_MESSAGE.
- 16.4.2.6. Press Buzzer Stop, and RESET.
- 16.5. OCL (Start Failure [Only in Auto-mode] OVER CRANKING)
 - 16.5.1. Change Mode to Auto-mode.
 - 16.5.2. Block out commercial power or earth CNT terminal.
 - 16.5.3. Start output is put out after S.D.T time.
 - 16.5.4. If Engine operating speed for 7 sec of starting time is not more than 30% of rated speed, repeat 7sec. start and 7sec. stop three times.
 - 16.5.5. OCL lamp is turned on, buzzer sounds, and engine stops.
 - 16.5.6. LCD screen displays OVER CRANK ERROR_MESSAGE.
 - 16.5.7. Press Buzzer Stop, and RESET.
- 16.6. OVER VOLTAGE, UNDER VOLTAGE, OVER CURRENT, AFR FAULT operate in the same way .as above ENGINE FAULT case.
- 16.7. 9. When PROTECT SETTING is ON, if faults are input, engine stops.
- 16.8. 9. When PROTECT SETTING is OFF, if Engine does not stop; only alarm and 86X operates; RESET after buzzer stops, Engine operates continually.
- 17. ABBREVIATIONS
 - 17.1. ECU-DG1 : ENGINE CONTROL UNIT
 - 17.2. MPU : MAGNETIC PICKUP
 - 17.3. ETS : ENERGIZED TO STOP , (fuel line is closed when engine stops)
 - 17.4. ETR : ENERGIZED TO RUN, (fuel line is opened when engine runs)
 - 17.5. RPM : TACHOMETER
 - 17.6. 5S : Stop Solenoid
 - 17.7. 86X : Operation relay in case of heavy faults input
 - 17.8. 14X : IDLE SPEED relay
 - 17.9. PB S/W : PUSH BOTTOM SWITCH
 - 17.10. EPB : EMERGENCY PUSH BOTTOM SWITCH